

ResMed Quattro™ FX Sizing Gauge

Cut out the internal sections in each sizing gauge. The only measurement is the length of space between the bridge of the nose and the dimple under the lower lip. Use the template to determine your size as best as possible.

When sizing, the top of the gauge cutout should be held at the bridge of the nose and the bottom of the gauge cutout should be just below the lower lip in the dip above the chin.

Try all 3 sizes to be sure.

